

# MERIDIAN RETAIL DISPLAY | SETUP INSTRUCTIONS



Secure base to lower poles with bolts & Allen wrench.



Once lower poles are tightened, place stand upright on its base.



Next, attach middle shelf to lower poles with bolts & Allen wrench.



Now attach upper poles to middle shelf with bolts from below.





Carefully slide slotwall panel into inner channel of poles.



Attach top shelf to upper poles with bolts. Then insert lower panels into front channels of lower poles by applying tension.



Finished!